




**Gama “Snack-Bar”**  
**Mantenedor caliente de pan**  
**MCP 20**  
**Lista de Piezas de Recambio**

Franke España, S.A.  
Apartado Correos, 174  
08100-Mollet del Vallès  
(Barcelona)

[www.franke.es](http://www.franke.es)  
[fss-comercialvt@franke.com](mailto:fss-comercialvt@franke.com)  
Telf: 902 240 021  
Fax: 900 444 445

**FRANKE**

# MCP 20



Pos.	Código	Denominación	Ref.	Cant.
1		Top cover	58003I308	1
2		Cable de red + clavija	C03001	1
3		Pasa cable	A10002	1
4		Resistencia	D02148	1
5		Termostato	A06049	1
6		Piloto luminoso	A08002	1
7	5389162	Mando	A14078	1
8		Pie	A13003	4
9		Plancha inferior	58007G010	1
10		Guía cajón	59000BAC	1
11	5389184	Empuñadura	A15028	1
12		Cubeta	F05050	1
13		Parrilla	59004P310	1
14		Tapa	59002COU	1
	5389535	Rueda cajón	B06049	2